INSTRUCTIONS:

1. Remove old aerator from faucet. Use wrench if necessary.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads on faucet for easier installation.
4. Install onto spout by hand.
5. Connect your regular female aerator or any device with regular female threads (not provided).
6. Turn on faucet. If leak occurs, tighten more firmly.

INSTRUCCIONES:

1. Quite el viejo aireador del grifo. Utilice una llave inglesa de ser necesario.
2. Quite todas las arendelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas del grifo para una instalación más fácil.
4. Instale en el surtidor de agua en forma manual.
5. Conecte su aireador regular hembra o cualquier dispositivo con roscas hembra regular (no proveído).
6. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.

For small male faucets with outside threads:



Warning: Product may contain sharp edges, use caution when installing.

Advertencia: *Este producto puede que tenga los bordes filosos, use precaución al instalar.*